

FIG 1.

Choose a position for the airer. It should fix into a load bearing structure (e.g. ceiling joists)
Can you raise and lower the clothesmaid without obstruction?
Is the fixing position for the cleat in line with the pulley position and into a solid structure?

Mark out two fixing positions in the ceiling:

- 0.7m apart for the 0.9m airer
- 1.0m apart for the 1.2m airer
- 1.2m apart for the 1.5m airer
- 1.4cm apart for the 1.8m airer
- 1.6cm apart for the 2.0m airer




FIG 2.

Drill two holes deep enough to take the threaded pulley shafts provided, using a 5mm drill bit.

The double pulley should go nearest the cleat hook.

If it takes much effort to screw in the pulleys enlarge the holes SLIGHTLY.
Use some oil to lubricate the pulley shaft.

Using the screws and rawlplugs provided attach the cleat to a solid, masonry or timber wall.

It is important when operating the airer that the pulleys and rope all run in a straight line to prevent friction (Otherwise the rope will wear quickly and eventually break).





FIG 3.

The rope needs to be cut into 2 pieces
(blue to single pulley / red through double pulley)

The rope to the single pulley will be longer by the distance between the pulleys.
Allow enough for the "loading height" when secured to the cleat.

Tie a knot on to each rack end and then thread around the pulleys and down to the wall cleat.

Then thread the slats through the rack ends.

Adjust each rope to ensure the drying rack is level (at loading height) and then tie a knot in both ropes.

The ropes should run freely through the pulley wheels.




FIG 4.

If you want to position your airer away from a wall you should use an extra double pulley - this will keep the rope out of the way and close to the wall or ceiling.

The angle from the pulley to the wall cleat should be steep enough to ensure the rope does not catch on the pulley frame.

You may also need a 15m rope if it's a large room or high ceiling.

Our INSTALLATION VIDEO will explain the whole process and is on our website



QR code - installation video